Items		Pre-ride	Frequency *1						Annual	Dagudag	Defeate
		Check ▶ P. 54	× 1,000 km	1	12	24	36	48	- Annual - Check	Regular Replace	
			× 1,000 mi	0.6	8	16	24	32			
Fuel Line	3/1/2				_	_	1	_	1		_
Fuel Level											44
Throttle Operation	3	1			1	1	1	1	1		90
Air Cleaner *2	3/1/2					R		R			_
Crankcase Breather *3					С	С	С	С	C		91
Spark Plug	3							R			_
Valve Clearance	3				1	1	1	1			_
Engine Oil				R	R	ß	B	R	R		71
Engine Oil Filter				R	R	R	R	R	R		73
Clutch Oil Filter			NC700XD	R		B		R			75
Engine Idle Speed	3				1	1	1	1	1		_
Radiator Coolant *4										3 Years	77
Cooling System	3					1	1	I			_

Maintenance Level

: Intermediate. We recommend service by your dealer, unless you have the necessary tools and are mechanically skilled. Procedures are provided in an official Honda Shop Manual.



: Technical. In the interest of safety, have your motorcycle serviced by your dealer.

Maintenance Legend

left: Inspect (clean, adjust, lubricate, or replace if necessary)

L : Lubricate

R: Replace

C : Clean

Items		Pre-ride Check ▶ P. 54	Frequency *1						1	D la	Defeate
			× 1,000 km	1	12	24	36	48	Annual Check	Replace	Refer to page
			× 1,000 mi	0.6	8	16	24	32			
Drive Chain		1		Every 1,000 km (600 mi):							83
Drive Chain Slider											86
Brake Fluid *4		1			1	1	1	1	1	2 Years	79
Brake Pads Wear											80
Brake System				1	1	1	1	1	1		54
Brakelight Switch											92
Brake Lock Operation	3		NC700XD	1	1	1	1	I			81
Headlight Aim											92
Lights/Horn		1									_
Engine Stop Switch											_
Clutch System		1	NC700X/XA	1	1	1	1	1	1		87
Side Stand											82
Suspension	3				1	1	1	1	1		_
Nuts, Bolts, Fasteners	3/1/2										-
Wheels/Tyres	1	1			I	1	1		1		61
Steering Head Bearings	3										_

Notes:

^{*1:} At higher odometer readings, repeat at the frequency interval established here.

^{*2 :} Service more frequently when riding in unusually wet or dusty areas.

^{*3 :} Service more frequently when riding in rain or at full throttle.

^{*4:} Replacement requires mechanical skill.